

STANDARD DEPARTURE CHART-5 - INSTRUMENT

ZAMA TRANSITION

From over MORIZ, proceed via CBE R-067 to TSUGU, then CHAUS, via 090DEG to DF NDB.

Cross CBE R-067/36DME at or above 12,000FT, cross CHAUS at or above FL190.

TENRU TRANSITION

From over MORIZ, proceed via CBE R-067 to TSUGU, then CHAUS, via MBE R-179 to TENRU.

Cross CBE R-067/36DME at or above 12,000FT, cross CHAUS at or above FL150.

KOWA TRANSITION

From over MORIZ, proceed via XMC R-039 to XMC VORTAC.

HAMAMATSU TRANSITION

From over MORIZ, proceed via LHE R-316 to LHE VOR/DME (LHT R-314 to LHT TACAN).

CHAUS TRANSITION

From over MORIZ, proceed via CBE R-067 to TSUGU, then CHAUS.

Cross CBE R-067/36DME at or above 12,000FT, cross CHAUS at or above FL150.

