

STANDARD ARRIVAL  
ROUTES – INSTRUMENT  
(STAR)BERLIN/SCHÖNEFELD  
(NORTH)  
RWY 07L

Designator	Identification Significant Points	Mag (True) Track	Dist NM	MNM IFR Cruising Level	Remarks
1	2	3	4	5	6
<b>BODLA 3Z</b>	<b>BODLA THREE ZULU</b>				1. BRNAV equipment necessary. 2. Arrange your flight to cross RADEL max. FL 140.
	△ BODLA				
	△ GOLBO	250 (252.2)	30.1	4000	
	△ RADEL	239 (241.2)	21.1	4000	
	△ LANUM	249 (250.8)	27.7	4000	
<b>RENKI 5Z</b>	<b>RENKI FIVE ZULU</b>				
	△ RENKI				
	△ RADEL	272 (274.2)	31.1	4000	
	△ LANUM	249 (250.8)	27.7	4000	
<b>GOLBO 1Z</b>	<b>GOLBO ONE ZULU</b>				
	△ GOLBO				
	△ RADEL	239 (241.2)	21.1	4000	
	△ LANUM	249 (250.8)	27.7	4000	
<b>BATEL 6Z</b>	<b>BATEL SIX ZULU</b>				1. BRNAV equipment necessary. 2. Arrange your flight to cross LANUM max. FL 140.
	△ BATEL				
	△ GIRIT	064 (066.4)	38.9	4000	
	△ LANUM	090 (091.9)	11.3	4000	
<b>VIBIS 2Z</b>	<b>VIBIS TWO ZULU</b>				
	△ VIBIS				
	△ LANUM	169 (170.7)	10.9	4000	