

BREMEN
RWY 27

STANDARD DEPARTURE
ROUTES – INSTRUMENT
(SID)

Designator	Route	After Take-Off		Remarks
		Climb to	Contact	
1	2	3	4	5
ERLAD 1Z	ERLAD ONE ZULU Climb straight ahead to 400ft; LT, complete turn within 1.3 DME BND, on track 199° to 2.8 DME BMN (3.1 DME BND); LT, on R312 NIE to intercept R162 BMN, on R162 BMN to ERLAD (△). GPS/FMS RNAV: DW270 [A500+; L] - DW276[L] - DW279[R]- ERLAD.	4000 ft	Bremen Radar 125.650	If unable to comply file ERLAD 1K.
ERLAD 1K	ERLAD ONE KILO Climb straight ahead via BMN on R267 BMN to 1.7 DME BMN; LT, on R312 NIE to intercept R162 BMN, on R162 BMN to ERLAD (△). GPS/FMS RNAV: [A500+] - DW271[L] - DW273 - DW279[R] - ERLAD.			
BASUM 3A	BASUM THREE ALPHA Climb straight ahead to 400ft; LT, complete turn within 1.3 DME BND, on track 199° to 2.8 DME BMN (3.1 DME BND); LT, on R312 NIE to intercept R175 BMN, on R175 BMN to BASUM (△). GPS/FMS RNAV: DW270 [A500+; L] - DW276[L] - DW278[R] - BASUM.			If unable to comply file BASUM 7K.
BASUM 7K	BASUM SEVEN KILO Climb straight ahead via BMN on R267 BMN to 1.7 DME BMN; LT, on R312 NIE to intercept R175 BMN, on R175 BMN to BASUM (△). GPS/FMS RNAV: [A500+] - DW271[L] - DW273 - DW278[R] - BASUM.			

(Sample: DW271 fly-over way point)

Contact Bremen Radar immediately after take-off!