

STANDARD DEPARTURE  
ROUTES – INSTRUMENT  
(SID)

SCHWERIN-PARCHIM  
06/24

Designator	Route	After Take-Off		Remarks
		Climb to	Contact	
1	2	3	4	5
<b>RWY 06</b>				
<b>BKD 4H</b>	<b>BRÜNKENDORF FOUR HOTEL</b> On track 063° to PI NDB, RT, on R033 BKD to BKD (Δ).	5000 ft	Bremen Radar   134.650	During activation times of ED-R 206, only usable at or below FL70.
<b>KUBAB 1H</b>	<b>KUBAB ONE HOTEL</b> On track 063° via PI NDB to 15.3 DME PMD; LT, on R036 BKD to KUBAB (Δ).			
<b>RWY 24</b>				
<b>BKD 3J</b>	<b>BRÜNKENDORF THREE JULIETT</b> On track 243° to 3.0 DME PMD; LT, on R011 BKD to BKD (Δ).	5000 ft	Bremen Radar   134.650	During activation times of ED-R 206, only usable at or below FL70.
<b>KUBAB 1J</b>	<b>KUBAB ONE JULIETT</b> On track 243° to 3.0 DME PMD; RT inbound PI NDB; LT, on track 063° to 15.3 DME PMD; LT, on R036 BKD to KUBAB (Δ).			