

STANDARD DEPARTURE  
ROUTES – INSTRUMENT  
RNAV (GPS) - SID

COBURG-BRANDENSTEINSEBENE  
RWY 12/30

Designator	Route	After Take-Off		Remarks
		Climb to	Contact	
1	2	3	4	5
<b>RWY 12</b>				
<b>LASGA 3E</b>	<b>LASGA THREE ECHO</b> On track 118° to QC001, LT, via QC002 on track 002° to LASGA (Δ). <b>RNAV (GPS):</b> [A2000+] - QC001[L] - QC002 - LASGA.	5000 ft	München Radar 129.525	Procedure not to be used during activity of NLFS.
<b>LONLI 3E</b>	<b>LONLI THREE ECHO</b> On track 118° to QC003, RT, on track 185° to LONLI (Δ). <b>RNAV (GPS):</b> [A2000+] - QC003[R] - LONLI.			
(Sample: QC001 fly-over way point)				
<b>RWY 30</b>				
<b>LASGA 1W</b>	<b>LASGA ONE WHISKEY</b> On track 298° to QC010 and 3000, RT, via QC013 on track 088° to LASGA (Δ). <b>RNAV (GPS):</b> [A2000+] - QC010[A3000; R] - QC013 - LASGA.	5000 ft	München Radar 129.525	
<b>LONLI 3W</b>	<b>LONLI THREE WHISKEY</b> On track 298° to QC010 and 3000, LT, via QC011 on track 179° to QC012, LT, on track 106° to LONLI (Δ). <b>RNAV (GPS):</b> [A2000+] - QC010[A3000; L] - QC011 - QC012[L] - LONLI.			
(Sample: QC010 fly-over way point)				