

STANDARD ARRIVAL CHART -INSTRUMENT

RJGG / CHUBU CENTRAIR

STAR

SOUTH ARC ARRIVAL

From over CARDS, proceed via CBE R-224, turn right via CBE 21DME counterclockwise ARC , then turn left....  
 From over CHES, proceed via CBE R-339, turn right via CBE 21DME counterclockwise ARC , then turn left....  
 From over SWING, proceed via CBE R-042, turn left via CBE 21DME clockwise ARC , then turn right....  
 From over SLIDE, proceed via CBE R-055, turn left via CBE 21DME clockwise ARC , then turn right....  
 From over TRIKE, turn left via CBE 21DME clockwise ARC , then turn right....

for ILS Z RWY36 and LOC Z RWY36 :

....to intercept and proceed via ICX-LOC to PROBE.  
 Cross CBE R-208 at or above 6,000ft, cross CBE R-195 at or above 5,000ft(when started from CARDS or CHES).  
 Cross CBE R-124 at or above 5,000ft(when started from SWING, SLIDE or TRIKE).  
 Cross PROBE at or above 3,500ft.

for VOR RWY36:

....to intercept and proceed via CBE R-174 to PIXIE.  
 Cross CBE R-208 at or above 6,000ft, cross CBE R-195 at or above 5,000ft(when started from CARDS or CHES ).  
 Cross CBE R-124 at or above 5,000ft(when started from SWING, SLIDE or TRIKE).  
 Cross PIXIE at or above 3,500ft.

