

STANDARD ARRIVAL CHART-INSTRUMENT-1

SHINODA ARRIVAL

From over SKE VOR/DME (SK NDB), via SKE R-065 to SKE 10DME, (066DEG from SK NDB until intercepting OWE R-152), turn left to intercept and proceed via OWE R-143 (140DEG from RK NDB) to IKOMA.

Cross SKE VOR/DME (SK NDB) at or above 4,000 FT, cross IKOMA at or above 3,500 FT.

YAMAT ARRIVAL

From over YAMAT, via OWE R-143 to IKOMA.

Cross YAMAT at or above 6,000 FT, cross IKOMA at or above 3,500 FT.

TENRI ARRIVAL

From over TENRI, via SIE R-097 to intercept and proceed via SIE 7DME clockwise ARC to intercept and proceed via OWE R-143 (140DEG from RK NDB), to IKOMA.

Cross TENRI at or above 4,000 FT, cross IKOMA at or above 3,500 FT.

