

STANDARD DEPARTURE CHART-10 - INSTRUMENT

Alternate transitions in case of outage of Naha and/or Chinen VORTAC (NHC/TIC)

**PACIFIC ALFA TRANSITION**

From over OK NDB, proceed via 052 DEG from OK NDB to BASHO, then turn left via ALC R-210 to TAMAK, DONAN or ALC VORTAC.

Cross ALC R-210/75DME at assigned or specified altitude.

**CHERY ALFA TRANSITION**

From over OK NDB, proceed via 052 DEG from OK NDB to CHERY.

**ADDAN ALFA TRANSITION**

From over OK NDB, proceed via 053 DEG from OK NDB to ADDAN.

Cross ADDAN at assigned or specified altitude.

**SAKON ALFA TRANSITION**

From over OK NDB, proceed via 207 DEG from OK NDB to SAKON.

Cross SAKON at assigned or specified altitude.