

STANDARD DEPARTURE CHART-2 - INSTRUMENT

KUMEJIMA THREE DEPARTURE

- RWY18 : Turn right, climb via NHC R-195 to intercept and proceed via NHC 14DME clockwise ARC to intercept and proceed via NHC R-265 to DORIS.
Maintain 1,000FT until NHC R-195/6DME....
- RWY36 : Turn Left, climb via NHC R-320 to intercept and proceed via NHC 14DME counterclockwise ARC to intercept and proceed via NHC R-265 to DORIS.
Maintain 1,000FT until NHC R-320/11DME....
....Cross NHC R-265/16DME at 2,000FT, cross DORIS at or above 3,000FT.

CHURA ONE DEPARTURE

- RWY18 : (Not established)
- RWY36 : Turn left, climb via NHC R-320 to intercept and proceed via NHC 14DME counterclockwise ARC....
.... to intercept and proceed via NHC R-240 to ELIEE.
.... to intercept and proceed via NHC R-195 to MAZDA.
.... to join AVLAS TRANSITION.
.... to join TOPAT TRANSITION.
.... to intercept and proceed via TIC R-050 to ANMAR
Maintain 1,000FT until NHC R-320/11DME, maintain 2,000FT until ELIEE or crossing NHC R-240.

CONEY ONE DEPARTURE

- RWY18 : Climb via NHC R-180 to intercept and proceed via NHC 20DME counterclockwise ARC....
.... to join AVLAS TRANSITION.
.... to join TOPAT TRANSITION.
.... to intercept and proceed via TIC R-050 to NABEE.
Maintain 2,000FT until NHC R-180/12DME.
For PACIFIC TRANSITION
Cross NHC R-110 between 12,000FT and FL150, cross NABEE at or above FL150.
For ADDAN TRANSITION, CHERY TRANSITION
Cross NHC R-110 at assigned or specified altitude.
- RWY36 : (Not established)