

BERLIN/SCHÖNEFELD  
(SOUTH)  
RWY 07L

STANDARD ARRIVAL  
ROUTES – INSTRUMENT  
(STAR)

Designator	Identification Significant Points	Mag (True) Track	Dist NM	MNM IFR Cruising Level	Remarks
NUKRO 4S	<b>NUKRO FOUR SIERRA</b>				Arrange your flight to cross NUKRO max. FL 140 and KLF max. FL 90.
	△ NUKRO				
	△ Klasdorf DVOR/DME	265	32	4000	
RUDAK 5S	<b>RUDAK FIVE SIERRA</b>				Arrange your flight to cross KLF max. FL 90.
	△ RUDAK				
	△ Klasdorf DVOR/DME	057	28	4000	
MILGU 2S	<b>MILGU TWO SIERRA</b>				1. Arrange your flight to cross KLF max. FL90. 2. BRNAV equipment necessary
	△ MILGU				
	△ NOLNI	059 (061.3)	12.6	4000	
	△ Klasdorf DVOR/DME	021	23	4000	
AKUDI 3S	<b>AKUDI THREE SIERRA</b>				Arrange your flight to cross KLF max. FL 90.
	△ AKUDI				
	△ Klasdorf DVOR/DME	351	27	4000 (5000)	