

STANDARD ARRIVAL
ROUTES – INSTRUMENT
(STAR)

MÜNCHEN
RWY 08/26

Designator	Identification Significant Points	Mag (True) Track	Dist NM	MNM IFR Cruising Level	Remarks
1	2	3	4	5	6
ABGAS 1A	ABGAS ONE ALPHA				<ol style="list-style-type: none"> 1. ROKIL is clearance limit. 2. BRNAV equipment necessary. 3. Cross LURER at or below: FL 140 for RWY 08, FL 160 for RWY 26, and ROKIL at or below FL 110. 4. Available a. daily 2230(2130) - 0700(0600), b. FRI 1600(1500) - MON 0700(0600), c. HOL. 5. Holding LURER by ATC only.
	△ ABGAS	131 (133.3)	11.5	5000 (FL 80)	
	△ LURER	080 (082.5)	14.3	5000 (FL 80)	
	△ LELTA	080 (082.7)	9.7	5000 (FL 80)	
	△ ROKIL	076 (077.8)	16.3	5000 (FL 80)	
△ Mike NDB					
AKANU 1A	AKANU ONE ALPHA				<ol style="list-style-type: none"> 1. ROKIL is clearance limit. 2. BRNAV equipment necessary. 3. Cross AKANU at or below FL 250, RENLO at or below: FL 130 for RWY 08, FL 150 for RWY 26, and ROKIL at or below FL 110.
	△ AKANU	134 (135.9)	10.7	5500 (FL 80)	
	△ LUPOX	134 (136.0)	12.3	5500 (FL 80)	
	△ RENLO	159 (161.1)	16.6	5000 (FL 80)	
	△ ROKIL	076 (077.8)	16.3	5000 (FL 80)	
△ Mike NDB					
ANORA 1A	ANORA ONE ALPHA				<ol style="list-style-type: none"> 1. ROKIL is clearance limit. 2. BRNAV equipment necessary. 3. Cross ANORA at or below FL 250, BURAM at or below: FL 130 for RWY 08, FL 150 for RWY 26, and ROKIL at or below FL 110. 4. Holding XERUM by ATC only
	△ ANORA	132 (133.6)	12.0	5000 (FL 80)	
	△ XERUM	132 (133.9)	10.0	5000 (FL 80)	
	△ BURAM	136 (137.9)	14.7	5000 (FL 80)	
	△ ROKIL	076 (077.8)	16.3	5000 (FL 80)	
△ Mike NDB					
ARBAX 1A	ARBAX ONE ALPHA				<ol style="list-style-type: none"> 1. LANDU is clearance limit. 2. BRNAV equipment necessary. 3. Cross OSTES at or below FL 110.
	△ ARBAX	203 (205.6)	6.8	7500 (FL 80)	
	△ USEMI	203 (205.5)	9.6	7500 (FL 80)	
	△ LITLI	203 (205.4)	17.2	7000 (FL 80)	
	△ OSTES	203 (205.3)	5.7	5000 (FL 80)	
	△ BINGU	262 (264.3)	7.0	5000 (FL 80)	
	△ TUSTO	262 (263.9)	6.7	5000 (FL 80)	
	△ LANDU	265 (266.9)	27.0	5000 (FL 80)	
	△ Mike NDB				
BAGMI 2A	BAGMI TWO ALPHA				<ol style="list-style-type: none"> 1. LANDU is clearance limit. 2. BRNAV equipment necessary. 3. Cross MITNU at or below FL 110. 4. Holding NETES by ATC only.
	△ BAGMI	203 (205.4)	10.1	7500 (FL 80)	
	△ ODUDA	203 (205.3)	11.2	7000 (FL 80)	
	△ NETES	203 (205.2)	7.3	5000 (FL 80)	
	△ UNKOM	198 (200.6)	6.1	5000 (FL 80)	
	△ MITNU	198 (200.5)	6.0	5000 (FL 80)	
	△ TUSTO	262 (263.9)	6.7	5000 (FL 80)	
	△ LANDU	265 (266.9)	27.0	5000 (FL 80)	
	△ Mike NDB				