

BERLIN-TEGEL
(SOUTH)
RWY 08

STANDARD ARRIVAL
ROUTES – INSTRUMENT
(STAR)

Designator	Identification Significant Points	Mag (True) Track	Dist NM	MNM IFR Cruising Level	Remarks
1	2	3	4	5	6
RUDAK 4Z	RUDAK FOUR ZULU				1. BRNAV equipment necessary. 2. Arrange your flight to cross LERSI max. FL 100.
	△ RUDAK △ LERSI	339 (341.7)	23.8	4000	
NUKRO 4Z	NUKRO FOUR ZULU				Arrange your flight to cross NUKRO max. FL 140 and KLF max. FL 110.
	△ NUKRO △ Klasdorf DVOR/DME	265	32	4000	
MILGU 2Z	MILGU TWO ZULU				1. Arrange your flight to cross KLF max. FL 110. 2. BRNAV equipment necessary
	△ MILGU △ NOLNI	059 (061.3)	12.6	4000	
	△ Klasdorf DVOR/DME	021	23	4000	
AKUDI 3Z	AKUDI THREE ZULU				Arrange your flight to cross KLF max. FL 110.
	△ AKUDI △ Klasdorf DVOR/DME	351	27	4000 (5000)	