

WAY POINT LIST

SIEGERLAND

GPS/FMS RNAV DEPARTURE ROUTES (OVERLAY)

IDENT	CODING		DISPLAY	
GS002	N 50 40 03.54	E 008 09 48.18	N 50 40.1	E 008 09.8
GS003	N 50 41 49.57	E 008 13 38.85	N 50 41.8	E 008 13.6
GS004	N 50 33 31.73	E 008 22 51.34	N 50 33.5	E 008 22.9
GS005	N 50 37 24.67	E 008 07 12.84	N 50 37.4	E 008 07.2
GS006	N 50 46 20.80	E 008 11 03.58	N 50 46.3	E 008 11.1
GS010	N 50 44 58.84	E 007 59 53.60	N 50 45.0	E 007 59.9
GS011	N 50 45 22.26	E 007 59 06.28	N 50 45.4	E 007 59.1
GS012	N 50 47 47.22	E 008 01 17.48	N 50 47.8	E 008 01.3
GS013	N 50 45 14.97	E 007 59 21.09	N 50 45.2	E 007 59.4
GS014	N 50 48 29.78	E 008 26 11.91	N 50 48.5	E 008 26.2
GS015	N 50 54 06.00	E 007 57 09.37	N 50 54.1	E 007 57.2
ARPEG	N 51 00 59.73	E 008 18 22.82	N 51 01.0	E 008 18.4
TOBAK	N 50 34 17.93	E 008 47 08.81	N 50 34.3	E 008 47.1

THRESHOLD COORDINATES

THR	CODING		DISPLAY	
RWY 31	N 50 42 13.64	E 008 05 26.62	N 50 42.2	E 008 05.4
RWY 13	N 50 42 45.93	E 008 04 21.63	N 50 42.8	E 008 04.4