

AERODROME  
CHART - ICAO



ARP  
62°32'05"N  
114°02'20"E

ELEV  
354m

START 134.100  
TOWER 1 125.900

MIRNY, RUSSIA

MIRNY



RWY	DIRECTION (TRUE)	THR	BEARING STRENGTH
07	055°54'	62°31'39.69"N 114°00'59.42"E	PCN 45 /R/A/W/T
25	235°54'	62°32'30.06"N 114°03'40.86"E	

ELEVATIONS AND DIMENSIONS IN METRES  
BEARINGS ARE MAGNETIC

CHANGE: COORD