



RWY	DIRECTION (TRUE)	THR	BEARING STRENGTH
05L	042°10.3'	48°30'59"N 135°10'11"E	PCN 56 /R/C/X/T
23R	222°10.3'	48°32'23"N 135°12'06"E	
05R	042°09.7'	48°30'53"N 135°10'22"E	PCN 68 /R/A/X/T
23L	222°09.7'	48°32'29"N 135°12'32"E	

WARNING
For take-off from RWY 23L and after landing on RWY 05R An-124, B747, Il-86, Il-96, B777, A-330 ACFT shall make 180-degree turn at the beginning of RWY 23L at turn pad. For take-off of An-124, B747, Il-86, Il-96, B777, A-330 ACFT from RWY 23L/05R ACFT shall taxi 200m from RWY THR. For RWY 23L/05R: TORA-3800m; TODA-4200m; ASDA-3800m.

ELEVATIONS AND
DIMENSIONS IN METRES
BEARINGS ARE MAGNETIC