


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

TRANSITION
LEVEL : **FL080**

VLADIVOSTOK, RUSSIA

KNEVICH I

RNAV (GNSS) RWY 07R



RADAR TOWER 119.5 126.0

WARNING
Crossing altitudes for exit points of AWY are as directed by ATS unit.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES