

AERODROME
CHART - ICAO

ARP
55°02'00"N
082°35'57"E

ELEV
112.5

START TAXIING
118.500
121.700

NOVOSIBIRSK, RUSSIA

TOLMACHEVO

PZ - 90.02 coordinates

RWY	DIRECTION (TRUE)	THR	BEARING STRENGTH
07	081°00'	55°00'35.68"N 082°37'21.52"E	PCN 69 R/C/X/T
25	261°03'	55°00'53.83"N 082°40'41.44"E	PCN 76 R/B/W/T
16	170°00'	55°02'57.10"N 082°35'39.43"E	
34	350°00'	55°01'02.38"N 082°36'14.63"E	

ELEVATIONS AND DIMENSIONS IN METRES
BEARINGS ARE MAGNETIC

