


AERODROME GROUND MOVEMENT
AND AIRCRAFT PARKING CHART - ICAO

START	118.3
TAXIING	121.7

NORILSK, RUSSIA

ALYKEL



Not to scale

TAXIWAYS:

Width: A, B - 22.5m
Surface: A, B - Concrete
Strength: A, B - PCN 68/R/A/X/T

WARNING

TWY 3, 4, 5 and MAIN TWY are closed.

ACFT types:

Il-86, Il-62, B757
Tu-204
B737-300, B737-400,
B737-500, B737-800
Tu-154
SAAB-2000
An-74
B757, Tu-214, A-319, A-320
An-30, An-32
Tu-134, An-24, An-26
An-12
Il-76
Tu-134

STANDS:

1, 2
1, 2, 7, 8, 15, 17 (3, 4-in autumn, winter)
1-4, 7, 8, 15-17
1-4, 7, 8, 12-17 (12-14 towing)
1-4, 15-17, 19, 20
3, 4, 13
7, 8
7-13, 19
7-13, 19 (9 towing)
9-13, 15-17, 20
15, 17, 20 (1, 2, 4-in autumn, winter)
14, 18 (are available as quarantine stands)

Parking of class below ACFT is permitted on class 1 ACFT stands.

WARNING

Stands 5, 6 are closed.

CHANGE: TWY C, D, E, F