


PZ-90.02 coordinates

CHANGE: CWY 05L/23R



RWY	DIRECTION (TRUE)	THR	BEARING STRENGTH
05L	052°34'	45°01'44.75"N 039°08'27.64"E	PCN 20 /R/B/X/T
23R	232°35'	45°02'28.04"N 039°09'47.43"E	
05R	052°35'	45°01'33.87"N 039°10'22.95"E	PCN 37 /R/B/X/T
23L	232°36'	45°02'32.91"N 039°12'11.84"E	

ELEVATIONS AND DIMENSIONS IN METRES BEARINGS ARE MAGNETIC