


STANDARD ARRIVAL CHART  
INSTRUMENT (STAR) - ICAO

TRANSITION  
LEVEL : **FL050**

**KRASNODAR, RUSSIA**  
PASHKOVSKIY  
RNAV GNSS RWY 05R



CHANGE: NIL

APPROACH **129.6 127.7**  
RADAR **121.3**  
TOWER **118.2**

**WARNING:**

1. Arrival and approach-to-land using RNAV procedure based on navigation satellite system GLONASS-GPS are available in the presence of permission (license) given by Federal Air Transport Agency of Ministry of Transport of Russia.
2. ACFT crew shall request the permission for GNSS approach from APP controller when passing reporting point of entry corridor.

**ⓘ WARNING**

Only for Russian users of airspace.

BEARINGS AND TRACKS ARE MAGNETIC  
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES  
DISTANCES ARE IN KILOMETRES