


AREA CHART - ICAO

ARRIVAL, DEPARTURE  
AND TRANSIT ROUTES

GROZNY, RUSSIA

SEVERNY



GROZNY KRUG (Additionally serves as LANDING, START)  
ATIS 120.2  
127.2

① HOLDING AREA  
NDB 408 WK  
1min - CAT A, B, C, D  
FL080-100

② Only for Russian users of airspace.

BEARINGS AND TRACKS ARE MAGNETIC  
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES  
DISTANCES ARE IN KILOMETRES

CHANGE: CTA, CTR boundary, FL, URR