


AREA CHART - ICAO

ARRIVAL, DEPARTURE
AND TRANSIT ROUTES

ROSTOV-NA-DONU, RUSSIA

TMA ROSTOV-NA-DONU



① Only for Russian users of airspace.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES

APPROACH	128.200
RADAR	121.200
ATIS	121.700 RUS 132.400 ENG

- WARNING:**
- The minimum safe altitude in TMA is 1285 with reference to the pressure of 760mm mercury column.
 - ACFT, carrying out transit flights through TMA, shall use SID and STAR routes.

CHANGE: BRG, FL, COM