


STANDARD DEPARTURE CHART
INSTRUMENT (SID) - ICAO

TRANSITION
HEIGHT : (900)

ROSTOV-NA-DONU, RUSSIA

ROSTOV-NA-DONU

RWY 04



START	119.700
RADAR	121.200
APPROACH	128.200

① Only for Russian users of airspace.

WARNING:

1. FL for passing the entry points on ATS routes shall be assigned by ATC.
2. After take-off immediately contact Rostov-Radar.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES