

**AIRCRAFT PARKING
CHART – ICAO**

TOWER	120.000
GROUND	119.000

YEKATERINBURG, RUSSIA

KOLTSOVO

20

STANDS:

- 1, 3, 4
- 6
- 7-9, 12, 25-27, 49-52
- 10
- 10A, 10B
- 11, 14, 15
- 13, 19-24, 30-33, 53, 55-58
- 25-29, 49
- 28A, 28B
- 36-39, 42-45
- 46, 47
- 54
- 28, 28A, 28B, 29, 49, 50, 55-58
- 59-62
- 63, 64
- 65, 66
- APN segment between stands 57-61
- On TWY G
- 1, 3, 4, 23, 24, 25
- 26
- 51
- 52
- TWY D segment between stands
- 39-42

ACFT types:

- Tu-154, A-321, A-320
- Il-96, Il-86, A-300-600, A-310, A-330, A-340, B747-100, B747-200, B747-300, B747SP, B767, B777
- Il-86, Il-62, Tu-204-100, Tu-204-300, Tu-204C, Tu-214, Tu-154, A-300-600, A-310, B767
- Il-96, A-340, B747-400, B777
- An-148, A-321, A-320, A-319, B737-200, B737-300, B737-400, B737-500, B737-600, B737-700, B737-800, ERJ-190, BAe-146
- Il-96, A-340, B747-100, B747-200, B747-300, B747SP, B777
- Tu-204-100, Tu-204-300, Tu-204C, Tu-214, Tu-154, An-148, A-319, A-320, A-321, B757-200, B737-200, B737-300, B737-400, B737-500, B737-600, B737-700, B737-800, ERJ-190, BAe-146
- Il-76TD, Il-76T, Tu-204-100, Tu-204-300, Tu-204C, Tu-214, An-12, An-148, Yak-42, A-319, A-320, A-321, B737-200, B737-300, B737-400, B737-500, B737-600, B737-700, B737-800, B727-200, ERJ-190, BAe-146
- An-124, Il-96, A-340, B747-400, B747-8, B747-8F, B777
- An-26, An-24, CRJ-200, Fokker 50, ATR-42, Yak-40, EMB-120ER, Mi-8 HEL
- An-26, An-24, SAAB-2000, ATR-72, CRJ-200, Fokker 50, Yak-40, EMB-120ER, Mi-8 HEL
- A-319, A-320, B737-200, B737-300, B737-400, B737-500, B737-600, B737-700, B737-800
- All HEL types
- B737-200, B737-300, B737-400, B737-500, ERJ-190, RRJ-95, Gulfstream, BAe-146, An-148, An-74, ATR-72, Jak-40
- PC-12, L-410
- Mi-8 HEL, L-410, PC-12
- B747
- All ACFT types
- Maintenance stands for carrying out the repair and scheduled maintenance works.
- Sanitary
- For washing of ACFT
- For ENG run-up
- For de-icing treatment of all ACFT types except B747 and B777 ACFT.

All stands can be used for PRKG of ACFT smaller than ACFT, indicated on the chart.