


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

MOSCOW, RUSSIA
VNUKOVO
RNAV RWY 01

TRANSITION
LEVEL: **By ATC**



CHANGE: New chart