

AERODROME  
CHART - ICAO


ARP  
N61°38.8'  
E050°50.7'

ELEV  
103.3m


SIVKAR START 124.6

SYKTYVKAR, RUSSIA

SYKTYVKAR



MARKING AIDS RWY 01 / 19 AND EXIT TWY



LIGHTING AIDS RWY 01 / 19 AND EXIT TWY



RWY	DIRECTION (TRUE)	THR	BEARING STRENGTH
01	021°46'	N61°38.2' E050°50.2'	PCN 49 /F/D/X/T
19	201°47'	N61°39.4' E050°51.2'	

ELEVATIONS AND  
DIMENSIONS IN METRES  
BEARINGS ARE MAGNETIC

CHANGE: New chart