



WARNING:

- 1. Stands can be used for PRKG of ACFT the geometrical dimensions of which (wingspan, ACFT LEN) are less than the dimensions of ACFT types, indicated on the chart.
- 2. Taxiing of M-101 GZHEL ACFT into stands 51, 52 shall be carried out by marshaller's instructions.
- 3. When stand P is occupied, using of stands 5, 6, 11, 12 is prohibited; when stand 49 is occupied, using of stands 47 and 48 is prohibited; when stand 49A is occupied, using of stands 45-48 is prohibited.
- 4. Turboprop ACFT engines start-up and taxiing out of stands 4 and 5 are prohibited.

ACFT types:

ACFT carrying out VIP flights
Il-96-400T

An-30
Il-76
Tu-154
Tu-154 with a wingspan 39m

Tu-134
Il-86, Il-62M, A-300, B767-300
A-310
B757-200
B737-800
A-319, A-320, Yak-42
ACFT the geometrical dimensions of which do not exceed the following:
wingspan 43.8m, length 46.7m
An-124, An-22, Mi-26, Il-96

BOMBARDIER GLOBAL EXPRESS,
A-321, A-330
Il-96-300, Tu-204
B767
M-101T GZHEL
Mi-8 HEL
Falcon-900, CRJ-100, CRJ-200,
SAAB-2000, SAAB-340, BAe125,
BAe146-200
Pilatus, ATR-42, ATR-72,
EMB-120
EMB-190/195, RRJ-95
L-410, Cessna-208B Caravan

STANDS:

P
on TWY 8 segments BTN
TWY 5/6 and TWY 9,
and BTN TWY 5/6 and TWY 7
3-6, 9-12, 45-48
15, 16, 35, 41-44
15-28, 33-41, 43-48, 49A
15, 16, 18, 22, 24, 25, 34, 35,
43-48, 49A
29-32
35, 44, 49A
15, 16, 35, 41, 43-44, 48, 49A, P
15-28, 33-35, 39, 43-48, 49A
15-29, 33-34, 49, 49A, P
15-29, 33-48, 49A

49
on TWY 8 BTN TWY 6, 9, BTN
TWY 6, 7 and on RWY 05/23
in the vicinity of TWY 2

15-44, 49, 49A, P
49A
P, 49A
51, 52
53-56

15-44, 49, 49A, P

3-6, 9-12, 45-48
15-44
3-6, 9-12