STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : ❶

BRATSK, RUSSIA
BRATSK
RWY 12



APPROACH FL200 or below **118.100**

TRANSITION LEVEL:
❶ - FL060 when atmospheric pressure at aerodrome level is 715mm mercury column or above;
- FL070 when atmospheric pressure at aerodrome level is 688mm mercury column or above but less than 715mm mercury column;
- FL080 when atmospheric pressure at aerodrome level is less than 688mm mercury column.

WARNING
Flights over dam of hydroelectric power station within radius 2750m at altitudes up to FL130 are PROHIBITED.

CHANGE: FL, FREQUENCY, MSH

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES