STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : ❶

YEKATERINBURG, RUSSIA
KOLTSOVO
RWY 08L



APPROACH	**125.9**
RADAR	**118.7**
TOWER	**120.0**

❶ TRANSITION LEVEL:
- FL050 when atmospheric pressure is 733mm mercury column or above;
- FL060 when atmospheric pressure is less than 733mm mercury column and is above 706mm mercury column.

WARNING
Cross CRP R121° D45.0 below FL090 - by ATS unit clearance.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES

CHANGE: DIST FM NDB AR, R areas