STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : ❶

YEKATERINBURG, RUSSIA
KOLTSOVO
RNAV (GNSS) RWY 26L



APPROACH	**125.9**
RADAR	**118.7**
TOWER	**120.0**

❶ TRANSITION LEVEL:
- FL050 when atmospheric pressure is 733mm mercury column or above;
- FL060 when atmospheric pressure is less than 733mm mercury column and is above 706mm mercury column.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES

CHANGE: CPR BAGOK COORD, BRG DIST FM CRP BAGOK, BRG DIST FM NDB MH, R area