STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : ❶

VORONEZH, RUSSIA
CHERTOVITSKOYE
RWY 12



APPROACH	FL200 or below	**125.9**
TOWER		**118.3**

❶ TRANSITION LEVEL:
- FL040 when atmospheric pressure is 746mm mercury column or above;
- FL050 when atmospheric pressure is less than 746mm and is 719mm or above.

WARNING
Altitudes of crossing the airway exit points are by ATC instruction.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES

CHANGE: OBST, COORD, R, P areas