STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : **By ATC**

ORENBURG, RUSSIA
ORENBURG
RWY 08



TOWER **128.0**

WARNING
Altitudes of crossing the airway exit points are by ATC instructions.

CHANGE: COORD

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES